



FITTING INSTRUCTIONS TO SUIT
Toyota Prado (Feb 98-Feb 03)
3.4 litre V6 petrol Auto/Manual
***PACEMAKER* HEADERS** part no. **PH 12660**

Note: Both header are designed to be fitted from underneath

- Place an anti zapper across battery terminals
- Remove air box cover to first box
- Remove heat shields from original manifold
- Remove factory manifolds and Y branch
- Remove transmission filler tube (auto only) and place to one side

Note: (automatic only) remove L/H kick back cable. Refer to Diagram 1

Note: RH top rear stud must be removed for ease of header fitment

Note: LH remove top middle and both top and bottom rear studs for ease of header fitment

- Place headers onto remaining studs
- Replace removed studs and tighten up headers
- Locate Y branch into position and tighten up to standard exhaust system first
- Bolt up y branch to headers second
- Replace air box to finish

Note: (automatic only) Pacemaker has supplied a 12 mm tube extension and new bolt to reposition filler tube further from the cylinder head to allow more room around headers. Refer to Diagram 2

