

# HERROD MOTOR SPORT

## FITTING INSTRUCTIONS TO SUIT HERROD HEADERS part no. **PH 4001 H**

- Place antizapper across battery terminals
- Remove all plugs and leads
- Unclip Oxygen plugs

### **R H side**

- Unscrew coolant reservoir & place to front of motor (there is no need to disconnect hoses)
- Wind steering wheel around until bolt connecting steering shaft to the steering rack is pointing rearward
- Remove upper & lower bolts, & disconnect steering shaft
- Unbolt exhaust manifolds
- Unbolt and disconnect bolts and studs from the rear bracket (including the exhaust)
- Remove manifold assembly
- Place sealant onto gasket & hang from front bolt
- Place header into engine bay & bolt upto tight

### **L H side**

- Unbolt exhaust manifold from head and rear bracket and remove from engine bay
- Place sealant onto gasket & hang from front bolt
- Place header into engine bay & bolt upto tight

### **TO Finish**

- Place sealant onto base gaskets & bolt bases into position
- Place sealant onto outlet gaskets & line up to hanger brackets & bolt up
- Replace Oxygen sensors
- Replace steering shaft, plugs leads & coolant reservoir