



FITTING INSTRUCTIONS TO SUIT
Mitsubishi Pajero (1997-2000)
3.5 litre V6 petrol Auto/Manual
PACEMAKER HEADERS part no. **PH 9350**

- Remove air box cover to first box
- Remove heat shields from original manifold
- Remove factory manifolds and Y branch

Note: LH side, gently bend brake lines away from header

Note: LH side, remove front drive shaft bolts to front diff maybe necessary to install headers

- Place headers onto remaining studs
- Bolt up but leave loose
- Replace removed studs and tighten up headers
- Locate Y branch into position and tighten up to standard exhaust system first
- Bolt up y branch to headers second
- Tighten remaining bolts to header
- Replace air box to finish

Note: LH side, when fitting to a manual, crack slave cylinder hose and roll hose up towards the floor and cable tie up to body work to create enough space from header.



FITTING INSTRUCTIONS TO SUIT
Mitsubishi Pajero (1997-2000)
3.5 litre V6 petrol Auto/Manual
PACEMAKER HEADERS part no. **PH 9350**

- Remove air box cover to first box
- Remove heat shields from original manifold
- Remove factory manifolds and Y branch

Note: LH side, gently bend brake lines away from header

Note: LH side, remove front drive shaft bolts to front diff maybe necessary to install headers

- Place headers onto remaining studs
- Bolt up but leave loose
- Replace removed studs and tighten up headers
- Locate Y branch into position and tighten up to standard exhaust system first
- Bolt up y branch to headers second
- Tighten remaining bolts to header
- Replace air box to finish

Note: LH side, when fitting to a manual, crack slave cylinder hose and roll hose up towards the floor and cable tie up to body work to create enough space from header.