



## PH 5039 Product Information

Trim using a die grinder as to diagram before installing headers.  
**Note: this applies to the Borg-Warner T 5 manual 5 speed only**  
This procedure does not apply to the Getrag manual or automatic transmission.

